



« 1993 Thunderbird/Cougar Table of Contents»

«Group 07: TRANSMISSION»


«Section 07-03: Transmission, Manual--M5R2»

---

## SPECIAL SERVICE TOOLS


T50T-100-A

Impact Slide Hammer




T61L-7657-A

Extension Housing Seal Replacer




T71P-4621-B

Pinion Bearing Cone Remover



T74P-77248-A

Extension Housing Seal Remover




T75L-1165-B


Axle Bearing/Seal Plate



T75L-7025-B  
Remover/Replacer Tube




T75L-7025-K  
Shaft Sleeve-Replacing




T75L-7025-P  
Shaft Collar




T77J-7025-C  
Remover/Replacer Tube




T77J-7025-F  
Locknut Staking Tool




T77J-7025-G  
Bell Housing Seal Replacer




T77J-7025-H  
Bearing Puller




T77J-7025-J  
Puller Ring




T77J-7025-L  
Countershaft Front Bearing Replacer




T84T-7025-B  
TOD Forcing Screw




T85T-7025-A  
Remover/Replacer Tube




T88T-7025-AR  
Mainshaft Locknut Wrench




T88T-7025-B  
Bearing Cone Replacer




T88T-7025-G  
Gear Installing Spacer



T88T-7025-H  
Ball Detent Inserter



T88T-7120-A  
Bearing Race Puller



Tool Number	Description
D82L-4201-C	Depth Micrometer
D84L-1123-A	Bearing Pulling Attachment
TOOL-4201-C	Dial Indicator with Bracketry

